

Jacuzzi® Hot Tubs Technical Bulletin

Important Note Regarding New Non-Countersunk Cabinet Screws



The newly released Jacuzzi Hot Tubs cabinet screws with flat heads (non-countersunk, P/Ns 6570-393, 6570-394, 6570-395, and 6570-396) take a special bit to avoid damaging the screw heads during installation and removal. The proper bit is a #1 (sometimes listed as S1 or R1) Robertson square-head

bit. Examples are shown at right.

Important Note: A Phillips head screwdriver will fit into the screw head, but due to the difference in mating surfaces between these screws and an actual Phillips head screw, it can easily cause damage to or strip the screw head.



#1
No. 1

POWER BIT